



## **Installation Instructions for Rivera Primo® Hard Sounds™ Speaker Pods**

**R**emove the OE storage boxes from the fairing lower (. If you have a fairing lower without the OE storage boxes, you need to purchase Harley part # 58757-04 for the necessary hardware). Open the existing holes on the fairing lower with an 11/64" drill bit. Using the 3 supplied stainless steel 10-32 x 1" screws, bolt the Hard Sounds™ speaker pods to the fairing lowers. Use the OE fasteners on all other locations.